



Part # 60079
2015-up Ford Mustang GT
V-8 5.0L

CGS Installation Instructions

PLEASE DIRECT ALL INSTALLATION QUESTIONS TO CGS @ (505) 902-0102
DO NOT CALL THE RETAILER IN WHICH YOU PURCHASED YOUR CGS SYSTEM

Thank you for choosing a CGS Axle back Exhaust System™ to power your vehicle. These instructions will take you through the installation of your new axle back exhaust system.

Kit includes:

Qty.	Description	Part#
1	Driverside Muffler Assy.	300-1121
1	Pass. side Muffler Assy.	300-1122



1) Remove stock Exhaust System

First start by removing the stock Mufflers and Tips by measuring 1/4" back from the welds on the back side of the mufflers. Mark your measurement and proceed to cut the pipe. Then slide the complete Muffler and Tip assy. carefully off of the rubber hangers. Once one side is done, then you will need to do the same on the other side.

2) Installing your Axle Back Exhaust System

Make sure all existing rubber hangers are still in place. Install the new CGS Muffler Assy. into the rubber hangers and line it up on the stock tailpipe. Once both CGS Muffler Assy. are lined up and straight they are ready to tack weld. After both sides are tacked into the correct position and you have double checked that everything is straight and line up, you are ready to weld.

3) Final checklist

Be sure that you don't have any leaks in your welding. That's it, a simple install with **a lot of results. Congratulations!** You just installed more horsepower to your Mustang by allowing it to breathe easier with a CGS Axle Back Exhaust System™.

Thank you again and enjoy your new CGS Axle Back Exhaust System™.



IF YOU HAVE ANY QUESTIONS, PLEASE CALL OUR TECH LINE @ (505) 902-0102, 9:00AM to 4:00PM, PST, MON-FRI.

WWW.CGSMOTORSPORTS.COM

REV 1/16